

# GP-S8 - INSTALLATION INSTRUCTIONS

## Supplemental – for GX

### Connecting the three wires

Wire Color	Connect to	Description
Black	<b>GND</b>	(Chassis Ground)
RED	<b>IGN</b>	(+12v Ignition Switch)
GREEN	<b>VSS</b>	(Vehicle Speed Sensor)
Pink	<b>SW</b>	(Switch)

The **Switch (SW)** line is on (providing a return to Chassis GND) when alarm is on.

Connect your external device (such as relay, light, horn etc.) as follows:

- If the device is non polarized like incandescent lights then connect one lead to **+12v** and the other lead to **SW**.
- If the device is polarized then connect the positive lead to **+12v** and the negative lead to **SW**.
- If experimenting, it is recommended adding a 1 Amp Fuse as shown in the following figure:

